SB4	400M
Safety	Modules

Installation and Operation Manual

LANGUAGE

ENGLISH



M.D. Micro Detectors CAT8ESB1261501 1/19



SB400M Safety Modules

Installation and Operation Manual

LANGUAGE

ENGLISH

CONTENTS

L.O INTRODUCTION	-
2.0 SB400M MODULE	
2.1 OPERATING MODES DESCRIPTION	
2.1.1 AUTOMATIC	
2.1.2 MANUAL	
2.1.3 CONNECTION OF K1 K2 EXTERNAL CONTACTO	
2.2 CONNECTION EXAMPLES	
2.2.1 CONNECTION OF AD SRM WITH AN LS BARRII MODE, WORKING RANGE=HI, K1K2 EXTERNAL CONTA MUTING=30s)	ER (MANUAL CTORS, TIMEOUT
2.3 MUTING FUNCTION	
2.3.1 Muting sequence	8
2.3.2 MUTING OVERRIDE FUNCTION	9
2.3.3 Override with mantained action control	10
2.3.4 Override with pulse control	10
2.4 INSTALLATION AND ELECTRICAL CONNECTIONS.	11
2.5 INSTALLATION AND ELECTRICAL CONNECTIONS.	11
2.5.1 Characteristics of the output circuit	12
2.5.2 Use of K1 and K2 auxiliary contact elements	12
2.5.3 Warnings regarding the connection cables	12
2.6 SIGNALS DESCRIPTION	13
2.7 The RESTART command	
2.8 K1K2 FEEDBACK input	
2.9 SYSTEM STATUS output	
2.10 DIMENSIONS	
2.11 TECHNICAL DATA SB400M2.12 STATUS INDICATORS / FAULT DIAGNOSIS	
2.12.1 Status indicators (BASE MODULE)	
2.12.2 Status indicators (BASE MODULE)	
2.12.3 Status Fault diagnosis	
2.12.4 Status indicators (MUTING MODULE)	
2.13 PERIODIC TESTS TO DO EVERY YEAR	
2.14 GUARANTEE	
ZIIT COMMITTE IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	

CA
Micro Detectors

SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH

! This symbol indicates an important personal safety warning. Failure to comply with the warning may result in very high risk for exposed personnel.

1.0 INTRODUCTION

The SB400M interface, connected to an IEC 61496 $-\frac{1}{2}$ certified type 4 safety light curtain and equipped with two autocontrolled PNP type solid-state outputs, is a type 4 ESPE (Electro sensitive Protective Equipment).

The other characteristics indicated above remaining constant, if the light curtain is type 2, the entire ESPE will be type 2.

The SB400M main features are the following:

- Inputs for the connection of one safety barrier with fail safe outputs
- Restart manual or automatic selectable
- 2 N.O. outputs with guided contact safety relays
- 1 system monitor PNP output
- 1 external contactors feedback input
- Muting function with two sensors logic
- 1 muting function enable input
- 1 muting lamp output
- Muting override function integrated
- Selectable muting timeout

The safety modules also guarantees that:

- the output lines are open if the barrier is intercepted;
- the output lines are enabled only with correct response times;
- in manual mode, maintenance of the RESTART contact closed is not interpreted as AUTO mode.

! For safe use of the device, it is essential to read and understand the contents of this handbook.

! Failure to comply with the prescriptions indicated in this handbook may result in very high risks for the operating personnel of the machine protected.

M.D. Micro Detectors CAT8ESB1261501 3/19

CA
Micro Detectors

SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH

2.0 SB400M MODULE

2.1 OPERATING MODES DESCRIPTION

OPERATING MODES SELECTION		
TERMINAL 6	TERMINAL 15	OPERATION
0 Vdc	+24 Vdc	Automatic
+24 Vdc	+24 Vdc through a N.O. contact	Manual
0 Vdc	0 Vdc	Non-permissible
+24 Vdc	+24 Vdc	conditions

Table 1

2.1.1 AUTOMATIC

In this operating mode, the outputs of the safety module follow the status of the photocell:

- with the protected area free (outputs of the barrier active), the relay outputs of the control unit are active.
- with the protected area occupied (outputs of the barrier de-activated), the relay outputs of the safety module are de-activated.




Figure 1

NOTE: refer to the "CONNECTON EXAMPLES" section to see the muting signals connection

! Use in manual mode (start/restart interlock activated) is mandatory in the case in which the safety device controls an access protecting a danger zone and once a person has passed through the opening, he/she may remain in the danger zone without being detected (use as trip device according to IEC 61496). Failure to comply with this rule may result in very serious risks for the persons exposed.

M.D. Micro Detectors CAT8ESB1261501 4/19

C
Micro Detectors

SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH

! Check correct functioning of the entire safety system (control unit+barrier) following each reinstallation. In particular, if the original operating mode was Manual, check that the unit has been reconfigured in this mode.

2.1.2 MANUAL

In this operating mode, the outputs of the control unit are activated only if the protected area is free and after sending the RESTART signal to the control unit using the push-button or by means of a specific command on the RESTART input (terminal 15).

Once the protected area has been occupied, the relay outputs are deactivated.

The sequence described above must be repeated in order to re-activate these.

The RESTART command is active with with a 0 Vdc ---> +24 Vdc transition.

The minimum duration of the command is 100 ms.




Figure 2

NOTE: refer to the "CONNECTON EXAMPLES" section to see the muting signals connection

M.D. Micro Detectors CAT8ESB1261501 5/19

C M
Micro Detectors

SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH

2.1.3 CONNECTION OF K1 K2 EXTERNAL CONTACTORS

In this operating mode, the outputs of the control unit are activated only if the protected area is free and after sending the RESTART signal to the control Control of external contactors K1K2 can be activated in both operating modes. If this control is to be used, the set of normally closed contacts of the external contactors must be connected to terminal 20 of the safety module (Figure 8 and Figure 9).




Figure 3

Automatic functioning with K1K2 relays




Figure 4

Manual operation with K1K2 relays

NOTE: refer to the "CONNECTON EXAMPLES" section to see the muting signals connection

M.D. Micro Detectors CAT8ESB1261501 6/19

C
Micro Detectors

SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH

2.2 CONNECTION EXAMPLES

2.2.1 CONNECTION OF AD SRM WITH AN LS BARRIER (MANUAL MODE, WORKING RANGE=HI, K1K2 EXTERNAL CONTACTORS, TIMEOUT MUTING=30s)




Figure 5

2.3 MUTING FUNCTION

! The muting function is a temporary suspension of the safety light curtain's protective function. Carefully check your risk analysis in order to assess whether the muting function is compatible with your application and what additional measures have to be taken.

The muting function generates a temporary, automatic interruption of the protective action of the barrier in order to permit normal transit of material through the guarded opening.

The muting function is activated when the system detects the object that interrupts the opening protected. In other words, when the system recognizes the material and distinguishes between this and any operator (in a potentially dangerous situation), it is enabled to bypass the light curtain temporarily, allowing the material to pass through the opening (Figure 11).

The muting sensors form the sensing system that decides whether the muting function is to be activated (or not). Control of the dangerous opening can be de-activated only by a correct sequence of interruption of the beams of the muting sensors.

M.D. Micro Detectors CAT8ESB1261501 7/19

CA	
Micro Detectors	

SB400M Safety Modules Installation and Operation Manual ENGLISH




Figure 6

Muting on palletizing system application example

2.3.1 Muting sequence

The timing diagrams in Figure 12 and Figure 13 show the correct signal sequence. The muting function is initiated by the contemporary occurrence of two events :

- When the two beams of the muting sensors are activated within a time limit of 4 sec.
- When the muting enable signal (terminal 11) is high (+24 Vdc)


The muting function is terminated by one of the following events:

- As soon as one of the muting sensors is no longer activated whichever occurs first.
- When the muting time-out limit is expired; in this case the OSSDs are brought to the offstate. The muting time-out limit can be selected at 30 s or ∞.
- I The muting enable command will only enable the muting function and should be generated at the appropriate time by the machine control system (e.g. When the muting function is needed); it has no effect on the deactivation of the muting function. If not used, fix the terminal 11 at +24 Vdc.
- ! Remember that muting is a temporary automatic suspension of the safety function. This means that a time limit is always mandatory. If a time out limit of 30 s is a too short time for a particular machine cycle, the configuration without time monitoring $(t=\infty)$ can be selected. In this case alternative solutions or additional measures shall be implemented to detected the condition of a muting function permananently active caused by accumulation of faults or by the muting sensors activated all the time. For example for the application of guarding the openings of a conveyor system (palletizers) by monitoring appropriate signals generated by the transport system to determinate if and when a pallet is in the detection zone.


M.D. Micro Detectors CAT8ESB1261501 8/19

€.	M.D. Micro Detectors Strada S. Caterina, 235 41122 Modena Italy Tel. +39 059 420411
Micro Detectors	Fax +39 059 253973 www.microdetectors.com info@microdetectors.com

SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH



Muting Cycle



Muting cycle closed by a timeout

2.3.2 MUTING OVERRIDE FUNCTION

The OVERRIDE function must be used when the machine stops due to incorrect muting activation sequences with the material obstructing the guarded opening.

In this situation, the OSSD outputs are not active as the barrier and/or at least one Muting sensor is occupied. In this condition the OVERRIDE request LED blinks (ref. "Status Indicators").

M.D. Micro Detectors CAT8ESB1261501 9/19

C
Micro Detectors

SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH

- ! This function activates the OSSD outputs making it possible to remove the material that is obstructing the protected field.
- ! Throughout the phase during which the OVERRIDE function is active, the OVERRIDE/MUTING light blinks. Check efficiency of this light periodically (during the Muting or Override phases).
- ! Warning!! The Override with pulse command automatically activates the outputs of the light curtain until both the light curtain and the muting sensors are free of obstacles again. During this period, the light curtain is unable to protect access to the guarded opening. Therefore, all operations must be carried out under the strict supervision of expert personnel.
- ! During the installation of the module be sure to avoid short circuits between the contacts 7 and 8.

The operator will use the Override mode previously selected.

- 1. Override with mantained action control.
- 2. Override with pulse control.

2.3.3 Override with mantained action control

This function is activated driving terminals 7 and 8 of the control unit to +24 Vdc at the same time (maximum delay = 400 ms) using for example a 2-way key selector with spring return;

PIN 7	PIN 8	CONDITION
0	0	Normal operation
24 Vdc	24 Vdc	OVERRIDE request

The maximum override duration is 15 minutes; it can be stopped for two different causes.

- @ When the selector is released or if the 15 minutes has been elapsed, override ends, deactivating the OSSD outputs, turning off the muting lamp and showing normal condition on the display. A new override condition can be started, releasing and rearming the selector.
- @ Once the opening has been cleared and the sensors are free again, override ends and GUARD condition (control unit in normal operation) is activated without necessity of further commands.

2.3.4 Override with pulse control

This function is activated inverting (maximum delay = 400 ms) the condition of pin 7 and 8 of the receiver using for example a push button (switch). During the override the 7 and 8 are not controlled.

PIN 7	PIN 8	CONDITION
0	24 Vdc	Normal operation
24 Vdc	0	OVERRIDE request

! The override condition can last a maximum of 15 minutes (repeatable).

M.D. Micro Detectors CAT8ESB1261501 10/19

C		
Micro Detectors		

SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH

- ! The function can only be re-started by pressing the pushbutton again (subject to the following conditions):
- 1. Maximum total OVERRIDE time (after n consecutive requests) = 60 min
- 2. Maximum number of consecutive requests for OVERRIDE = 30.
- ! The override condition ends when the barrier and sensors are cleared (entrance clear) and the GUARD condition is re-enabled (barrier fully operational) without sending any further commands.
- ! The timer (point 1) and counter (point 2) are reset when one of the following conditions occurs:
- A correct muting sequence.
- A system reset (switched off and then turned on).

2.4 INSTALLATION AND ELECTRICAL CONNECTIONS

13 😩 15
000
16 17 18
000
IN 🔵
FAIL 🛑
GUARD Break
SB400M
000
19 20 21
000
22 23 24

LED	COLOR	STATUS	CONDITION
S1 Green	OFF	Muting sensor 1 free	
	Gie	ON	Muting sensor 1 interrupted
S2 Red	OFF	Muting sensor 2 free	
32	Reu	ON	Muting sensor 2 interrupted
		OFF	Correct operation
		ON	Muting active
MUT	Yellow		Override request
		Blinking	Muting fail (only with FAIL
			LED ON) *
IN Green	Croon	OFF	Barrier interrupted
	Green	ON	Barrier free
FAIL Red	OFF	No Failure	
	Reu	ON	Failure detected *
GUARD BREAK Green / Red / Yellow	RED	Output relays opened	
			The number of blinking shows
	Groon /	RED blinking	the kind of FAIL (only with
			FAIL is ON) *
	-	GREEN	Output relays closed
	1 CIIOW		Barrier free – Output relays
		YELLOW	opened (only in manual
			mode)
Table 2			

Table 2

Figure 9

* M.D. MICRO DETECTORS TO THE "FAULT DIAGNOSI" SECTION TO HAVE A DETAILED EXPLANATION OF THE POSSIBLE FAULT

2.5 INSTALLATION AND ELECTRICAL CONNECTIONS

- ! Install the SB400M safety module in an environment with a protection rating of at least IP54.
- ! If more modules SB400M must be installed in the same board panel, in order to avoid overheatings, maintain between them one minimal distance of 2 cm.
- ! The SB400M control unit must be supplied with a 24 Vdc \pm 20%.
- ! The external power supply must comply with the standard EN 60204-1.
- ! During the installation of the SB400M control unit be sure to avoid short circuits between the contacts 17 and 18.

M.D. Micro Detectors CAT8ESB1261501 11/19

CA
Micro Detectors

SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH

2.5.1 Characteristics of the output circuit

For the output circuit, the control unit uses two guided contact safety relays.

These relays are rated by the manufacturer for voltage and current values above those indicated in the technical data; however, to assure correct insulation and to avoid damage or premature aging, protect each output line with a 4 A slow-blow fuse and check that load characteristics comply with the indications given in the table below.

Minimum switching voltage	18 Vdc
Minimum switching current	20 mA
Maximum switching voltage	250 Vac
Maximum switching current	2 A

2.5.2 Use of K1 and K2 auxiliary contact elements

For loads with higher voltage and current characteristics than those indicated in the table above, use of auxiliary external relays or contactors suitable for the load to be controlled is recommended.

- The K1 and K2 auxiliary contactors or relays must be of the guided contact safety type.
- Referring to the table below, pay particular attention to the configuration of the control
 contacts on terminal 20 and that of the contacts of use.

	Relay K1	Relay K2
Control contacts	K1-1 normally closed	K2-1 normally closed
Use contacts	K1-2 normally open	K2-2 normally open

- Control contacts K1-1 and K2-1 (terminal 20) must be able to switch a current of 20 mA and a voltage of 24 Vdc.
- To increase the electrical life of internal relays A and B, it is advisable to use antidisturbance devices which must be connected across the coils of K1 and K2.

2.5.3 Warnings regarding the connection cables

- For light curtain/control unit connections of more than 50 m, cables with a cross-section of at least 1 mm² must be used.
- It is good practice to separate the power supply of the control unit from that of other electrical appliances (electrical motors, inverters, frequency variators) or other sources of disturbance.
- The path of the connection cables between the control unit and the sensors, the connection referring to the test command and feedback contacts connected to terminal 20 must be different from that of other power cables.

M.D. Micro Detectors CAT8ESB1261501 12/19



SB400M	LANGUAGE	
Safety Modules		
Installation and Operation Manual	FNGI TSH	

2.6 SIGNALS DESCRIPTION

TERMINAL NUMBER	SIGNAL NAME	TYPE OF SIGNAL	DESCRIPTION
1	SENSOR 1	Input	Muting Sensor n°1
2	SENSOR 2	Input	Muting Sensor n°2
3	24 Vdc	Input	Power supply 24 Vdc
4	TIMEOUT 1	Input	Timeout selection n°1 *
5	TIMEOUT 2	Input	Timeout selection n°2 *
6	MAN / AUTO	Input	Manual/Automatic configuration
7	OVERRIDE 1	Input	Override selection n°1 **
8	OVERRIDE 2	Input	Override selection n°2 **
9	N.C.	-	-
10	MUTING LAMP	Output	Muting lamp output
11	MUTING ENABLE	Input	External muting enable input
12	Relay B NO 1	Output	Safety relay B, contact 1 (N.O.)
13	0 Vdc	Input	Power supply 0 Vdc
14	PE	-	Ground connection
15	RESTART	Input	Restart command Input
16	N.C.	-	-
17	INPUT1 BARR	Input	Barrier input 1
18	INPUT2 BARR	Input	Barrier input 2
19	N.C.		-
20	K1/K2 (Feedback)	Input	K1K2 external contactors feedback
21	SYSTEM STATUS	Output	Output safety relays status
22	Relay B NO 2	Output	Safety relay B, contact 2 (N.O.)
23	Relay A NO 1	Output	Safety relay A, contact 1 (N.O.)
24	Relay A NO 2	Output	Safety relay A, contact 2 (N.O.)

Table 3

* M.D. MICRO DETECTORS TO THE Table 4 FOR THE SELECTION OF THE MUTING TIMEOUT Read carefully the "muting sequence" section to select the right timeout

SELECTION OF THE MUTING TIMEOUT		
TERMINAL 4	TERMINAL 5	DURATA TIMEOUT
0 Vdc	+24 Vdc	<i>30 s</i>
+24 Vdc	0 Vdc	Infinite
0 Vdc	0 Vdc	Conditions
+24 Vdc	+24 Vdc	not allowed

Table 4

** REFER TO THE Table 5 FOR THE SELECTION OF THE OVERRIDE

SELECTION OF THE MUTING TIMEOUT		
TERMINAL 7	TERMINAL 8	DURATA TIMEOUT
0 Vdc	0 Vdc	Spring return key
0 Vdc	+24 Vdc	Push button
+24 Vdc	0 Vdc	Conditions
+24 Vdc	+24 Vdc	not allowed

Table 5

M.D. Micro Detectors CAT8ESB1261501 13/19

C
Micro Detectors

SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH

2.7 The RESTART command

- The RESTART command must be sent to the control unit connecting terminal 15 to the +24 Vdc.
- The contact used for the RESTART command must be able to switch a voltage of 24 Vdc and a current of 20 mA (guaranteeing a closing time > 100 ms). This data is particularly important in the case of automatic management of sending of the RESTART command, for example using a PLC.
- The SYSTEM RESET TIME is obtained adding the reset time of any external contactors K1K2 to the reset time of the SB400M control unit (100 ms).
- In the case of manual activation, a normally open external button can be used, temporary closing of which generates the RESTART command.

! The Restart command must be installed outside the danger area in a position where the danger area and the entire work area concerned are clearly visible.

! It must not be possible to reach the RESTART control from inside the danger area.

2.8 K1K2 FEEDBACK input

Using the K1 and K2 auxiliary safety contactors with guided contact safety type, it is necessary to connect the +24 Vdc to the K1K2 FEEDBACK through the series of the K1-1 e K2-1 N.O. control contacts. The control of the correct switching of K1 and K2 is performed with a delay of 300ms after the real command. When the K1-1 e K2-1 N.O. control contacts are not used (or no control is provided) it is mandatory to connect the terminal 20 (K1K2 FEEDBACK) to the terminal 21 (SYSTEM STATUS).

2.9 SYSTEM STATUS output

The SYSTEM STATUS output reports exactly the output safety relays status:

- When the output relays are opened, the SYSTEM STATUS reports 0 Vdc.
- When the output relays are closed, the SYSTEM STATUS reports +24 Vdc.

2.10 DIMENSIONS




Figure 10

M.D. Micro Detectors CAT8ESB1261501 14/19

C M
Micro Detectors

SB400M Safety Modules Installation and Operation Manual ENGLISH

2.11 TECHNICAL DATA SB400M

Safety category Type 4	
Power supply Vdc $24 \pm 20\%$	
Output Relay 2 N.O. contacts (2 A; 250 V)	
Response time ms 20 max	
Operating modes Manual or Automatic, selectable from termina	l block
External Relay control 2 N.C. contacts (20 mA; 24 Vdc)	
Number of connectable 1 (with 2 PNP safety static outputs)	
Darriers	
Muting sensors input 2 sens. (24 Vdc; PNP; dark-on)	
Muting enable input 24 Vdc, PNP	
Time-out Override min 15	
System Status Output 100 mA; 24 Vdc	
Muting lamp output 24 Vdc / 0,5 ÷ 5 W	
Connections Terminal block with protection against rever	sal of
polarity	
Status indicator LEDs Power On – Barrier status – Fail	
Max. length of connections M 100	
Operating temperature °C 0 ÷ 55	
Enclosure protection rating IP 20	
Terminal block protection IP 2X	
rating	
Fast attachment to rail according to EN 5002	22-35
Dimensions (h x w x d) mm 99 x 22,5 x 114,5	
Weight g 150	
B10d 800.000	
Device lifetime 20 years	
Turno 4 IEC 61496-1:2004	
Type 4 IEC 61496-2:2006	
Safety level SIL 4 IEC 61508:1998	
SILCL 4 IEC 62061:2005	
Cat. 4 ISO 13849-1 : 2006	

Load	Number of Commutations	PFHd *	DCavg #	MTTFd #	PL#	CCF #
2 A @ 230Vac	1 every 30 s	2,80E-08	98,89%	25,97	d	80%
	1 every min	1,71E-08	98,78%	49,92	е	80%
	1 every hour	6,58E-09	98,78%	100,00	е	80%
	1 every day	6,42E-09	96,25%	100,00	е	80%
0,5 A @ 24Vdc	1 every 30 s	5,03E-08	98,94%	13,25	d	80%
	1 every min	2,80E-08	98,89%	25,97	d	80%
	1 every hour	6,76E-09	97,01%	100,00	е	80%
	1 every day	6,43E-09	96,28%	100,00	е	80%

Table 6

2.12 STATUS INDICATORS / FAULT DIAGNOSIS

M.D. Micro Detectors CAT8ESB1261501 15/19

^{*} IEC 61508

[#] ISO 13849-1

C M
Micro Detectors

SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH

2.12.1 Status indicators (BASE MODULE)

LED			
IN (GREEN)	FAIL (RED)	GUARD / BREAK (RED/YELLOW/GREEN)	MEANING
ON	ON	Red	Power up test
OFF	OFF	Red	Photocell interrupted Output relays opened
ON	OFF	Yellow	Photocell free Output relays opened
ON	OFF	Green	Photocell free Output relays closed

Table 7

2.12.2 Status indicators (BASE MODULE)

LED				
SENSOR1 (YELLOW)	SENSOR2 (YELLOW)	MUTING (YELLOW)	MEANING	
ON	ON	ON	Power up test	
OFF	OFF	OFF	Both the sensors are free	
ON	OFF	OFF	Sensor 1 interrupted	
OFF	ON	OFF	Sensor 2 interrupted	
ON	ON	ON	Muting active	
Shows the sensor 1 status	Shows the sensor 2 status	Blinking	Override request	

Table 8

2.12.3 Status Fault diagnosis

LED			
IN GREEN	FAIL RED	GUARD/BREAK RED/GREEN (pulses LED Red)	MEANING
OFF	ON	(2 pulses)	Internal fault
OFF	ON	(3 pulses)	Internal relays fault
OFF	ON	(4 pulses)	K1K2 external relays fault
OFF	ON	(5 pulses)	User configuration failure
OFF	ON	(6 pulses)	User configuration changed without system restart: Switch off and restart the module to solve the problem. At the switch on verify the new user configuration
OFF	ON	(7 pulses)	Possible overload or SYSTEM STATUS connection error

Table 9


M.D. Micro Detectors CAT8ESB1261501 16/19

C
Micro Detectors

SB400M Safety Modules Installation and Operation Manual ENGLISH

2.12.4 Status indicators (MUTING MODULE)

NOTE: The following status signals are present with the base module permanently light on.




! If it is not possible to clearly identify the malfunction and to to remedy it, stop the machine and contact the M.D. Micro Detectors's Assistence Service.

M.D. Micro Detectors CAT8ESB1261501 17/19



SB400M Safety Modules	LANGUAGE
Installation and Operation Manual	ENGLISH

2.13 PERIODIC TESTS TO DO EVERY YEAR



M.D. Micro Detectors CAT8ESB1261501 18/19



SB400M	LANGUAGE	
Safety Modules		
Installation and Operation Manual	ENGLISH	

2.14 GUARANTEE

M.D. Micro Detectors warrants that each SB400M unit in new ex-factory condition, in conditions of normal use, is free of defects in the materials and of manufacturing defects for a period of 24 months.

In this period, M.D. Micro Detectors undertakes to eliminate any faults in the product through repair or replacement of the faulty parts, completely free of charge as regards material and labor. However, M.D. Micro Detectors reserves the right to replace the entire faulty appliance with another equivalent appliance or with the same characteristics instead of repairing this.

Validity of this warranty is regulated by the following conditions:

- The user must inform M.D. Micro Detectors of the fault within 24 months from the date of delivery of the product.
- The appliance and its components must be in the conditions in which they were delivered by M.D. Micro Detectors.
- The serial numbers must be clearly legible.
- The fault or defect has not been caused directly or indirectly by:
- Improper use;
- Non-compliance with instructions for use;
- Carelessness, inexperience, incorrect maintenance;
- Repairs, modifications, adaptations not carried out by M.D. Micro Detectors personnel, tampering, etc.;
- Accidents or impacts (also due to transportation or causes of force majeure);
- Other causes not to be ascribed to M.D. Micro Detectors.

Repairs will be carried out at the M.D. Micro Detectors laboratories to which the material must be delivered or dispatched: transport risks and the risks of any damage or loss of the material during shipment are the responsibility of the user.

All products and components replaced become the property of M.D. Micro Detectors.

M.D. Micro Detectors does not recognize any other warranties or rights except for those specifically described above; therefore, no claims for damages may be submitted for expenses, interruption of business or other factors or circumstances in any way related to failure of the product or of one of its parts.

Precise, complete compliance with all the rules, instructions and prohibitions indicated in this handbook is an essential requirement for correct functioning of the safety interface.

M.D. Micro Detectors s.p.a. therefore declines any responsibility for all and anything resulting from failure to comply, even partially, with such indications.

Characteristics subject to change without notice.

Total or partial reproduction is forbidden without the prior authorization of M.D. Micro Detectors.

M.D. Micro Detectors CAT8ESB1261501 19/19